CABINET PARTS

REFRIGERATOR

For Models: GB22DKXGW00, GB22DKXGN00, GB22DKXGB00
(White) (Almond) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GB22DKXGW00, GB22DKXGN00, GB22DKXGB00
(White) (Almond) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Cabinet (Not a Service Part)
3		Plug, Button (3)
	4344191	White
	4344189	Almond
	4344190	Black
4		Plug, Button (3)
	4344535	White
	4344534	Almond
	4344533	Black
5	4344291	Roller, Front Assy.
6	4344155	Clip, Grille
7	4344177	Pin, Center Hinge
8		Shim
	4344188	White
	4344201	Black
10		Hinge Cover, Bottom
	4344204	White
	4344203	Almond
	4344202	Black
11	4344186	Screw
13		Shim, Hinge Top
	4344194	White
	4344193	Almond
	4344192	Black
14	4344198	Screw
15	4344179	Hinge, Center
16		Shim, Center Hinge
	4344176	White
	4344175	Almond
	4344174	Black
17	4344295	Housing, Roller
19		Hinge Bottom
	4344285	White
	4344284	Black
20	4343782	Screw
21	4344178	Pin, Bottom Hinge
22		Grille
	4344574	White
	4344573	Almond
	4344572	Black
23	4344267	Screw
24	4344264	Plug, I/M
25	4343759	Screw
26	4344257	Wire Cover
27	4344261	Back Cover
28	4344386	Harness, Control
29	4344266	Plate, Water Valve
30	4344262	Cover, Unit
31	4344210	Plug, Button
32	4344263	Power Cord
33	4344259	Grommet
34	4344260	PLug
39	4344265	Clip
40	4344286	Shim, Hinge
41	4344172	Hinge Top
42		Hinge Cover
	4344197	White
	4344196	Almond
	4344195	Black
43		Plate, Hinge Tap
	4344299	Right Side
	4344301	Left Side
44	4344290	Screw
45	4344293	Screw
46	4344298	Foot Break

FREEZER LINER PARTS

For Models: GB22DKXGW00, GB22DKXGN00, GB22DKXGB00
(White) (Almond) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: GB22DKXGW00, GB22DKXGN00, GB22DKXGB00
(White) (Almond) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Seviceable Part)
4	4344205	Light Lens
5	4344206	Screw
6	4344318	Light Socket
7	4343682	Clip−Ground
8	4344396	Screw
9	4343660	Light Bulb
10	4344319	Housing, Frz. Light
11	4344387	Cover, Evaporator
12	4344167	Screw
13	4344211	Washer (4)
14	4343928	Cover, Switch
16	4344571	Switch, Light
17	4344166	Cover, Plug
18	4344315	Plug, Button
19	4344228	Plug, Button
20	4344216	Gasket, Bottom
21	4343886	Gasket, Top (2)
22	4344388	Cover, Fan Shroud
23	4344587	Gasket
24	4344230	Gasket
25	4344390	Evap, Fan Shroud
26	4343657	Grommet, Screw
27	4344391	Fan, Evaporator
28	4344392	Bracket, Motor
29	4343934	Grommet
30	4344304	Motor, Evaporator
31	4344393	Bracket
32	4343749	Screw (4)
33	4344227	Plug, Button
34	4344222	Duct, Return Air
36	4343860	Screw
37	4344214	Knob, Control
38	4344224	Screw
39	4344226	Cover, Frz. Control
40	4343861	Screw
41	4344225	Thermostat
43	4344578	Bracket, Control
44	4344316	Plug, Button
45	4344321	Grommet
47	4344385	Funnel−Drain (Includes 48 & 49, seal & gasket)
48	4344311	Seal
49	4344310	Gasket

FREEZER DOOR PARTS

For Models: GB22DKXGW00, GB22DKXGN00, GB22DKXGB00
(White) (Almond) (Black)



Illus. No.	Part No.	DESCRIPTION
1		Freezer Door Panel (Includes Insulation)
	4344349	White
	4344348	Almond
	4344347	Black
2		Handle
	4344162	White
	4344161	Almond
	4344160	Black
3		Plug, Button
	4344159	White
	4344158	Almond
	4344157	Black
4	4344436	Screw
5	4344355	Interior Panel
6	4344582	Trim, Shelf
7	4344352	End Cap
8		Door Gasket, Magnetic
	4344354	White
	4344353	Black
9	4344170	Divider, Door Shelf
10	4344350	Insulation
12		Door, Stop
	4344463	White
	4344456	Almond
	4344563	Black
13	4344333	Screw
14		Plug, Button
	4344535	White
	4344534	Almond
	4344533	Black
17		Bushing
	4343945	White
	4343944	Black
18		Plug, Button
	4344227	White
	4344364	Black
19	4343811	Screw
20	4344199	Support−Pin

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Models: GB22DKXGW00, GB22DKXGN00, GB22DKXGB00
(White) (Almond) (Black)



Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	4343927	Housing, Ref. Light
3	4343928	Cover, Light Switch
4	4344571	Light Switch
5	4343682	Ground Clip
6	4344167	Screw
10	4344211	Washer (4)
11	4344206	Screw (8)
12	4344169	Egg Bin
13	4344321	Grommet
14	4344167	Screw
15	4344182	Control, Damper
16	4344184	Insulation, Damper
17	4344181	Shield, Light
18	4344325	Socket, Dual
19	4344185	Gasket
20	4343660	Light Bulb (2)
21	4343726	Light Lens, Top
22	4343675	Screw
23	4343681	Gasket, Damper
24	4343650	Insert
25	4344183	Cover, Control
26	4344180	Knob, Control
29	4344241	Plug, Button

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: GB22DKXGW00, GB22DKXGN00, GB22DKXGB00
(White) (Almond) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: GB22DKXGW00, GB22DKXGN00, GB22DKXGB00
(White) (Almond) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door Panel (Includes Insulation)
	4344584	White
	4344585	Almond
	4344586	Black
2	4344340	Interior Panel
3		Door, Compartment
	4344335	Left Side
	4344336	Right Side
4	4344337	Trim, Comp. Door
5	4344435	Screw
7		Cap, Handle Top
	4344165	White
	4344164	Almond
	4344163	Black
8		Door Gasket, Magnetic
	4344339	White
	4344338	Black
9		Door Handle
	4344147	White
	4344146	Almond
	4344145	Black
10	4344342	Hinge Pin
12	4344251	Shelf Bin (4)
13		Extension, Handle
	4344150	White
	4344149	Almond
	4344148	Black
14	4344583	Trim, Door Shelf
15	4343653	Screw
16	4344346	Plug−Trim
17		Stop, Door
	4344463	White
	4344456	Almond
	4344563	Black
18		Plug, Button
	4344535	White
	4344534	Almond
	4344533	Black
19	4343811	Screw
21	4344333	Screw
22	4344167	Screw
23		Bushing
	4344362	White
	4344361	Black
24		Plug, Button
	4344227	White
	4344363	Almond
	4344364	Black
25		Nameplate
	4344577	White
	4344576	Almond
	4344575	Black

UNIT PARTS

For Models: GB22DKXGW00, GB22DKXGN00, GB22DKXGB00
(White) (Almond) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: GB22DKXGW00, GB22DKXGN00, GB22DKXGB00
(White) (Almond) (Black)

Illus. No.	Part No.	DESCRIPTION
1	4343865	Screw
2	4344271	Fan, Blade
3	4344270	Condenser & Pan Assembly
5	4343691	Screw
6	4343860	Screw
7	4344217	Heat Shield
8	4344394	Drain Pan
10	4344232	Evaporator Heater
11	4343852	Cover
12	4343849	Overload
13	4344275	Gasket
14	4344231	Bi−Metal
15	4343850	Relay
16	4344278	Bracket, Timer
17	4343851	Capacitor
18	4344277	Shield, Capacitor
19	4343969	Clip, Wire
20	4344389	Drain Pan
22	4344233	Evaporator
24	4344419	Motor, Fan
25	4343918	Clip, Heater
26	4344569	Harness, Unit
27	4344268	Drier
28	4343856	Compressor (Includes Items 11, 12, 15, 17 & 27)
30	4344282	Washer
31	4344554	Shroud
32	4344272	Bracket, Fan Motor
33	4344395	Screw (2)
34	4343763	Clip, Drier
35	4344570	Cover, Timer
36	4344234	Block, Evaporator
37	4343759	Screw
38	4344280	Timer, Defrost
39	4343845	Grommet (4)
40	4344562	Screw
42	4344219	Clip, Evaporator
43	4343772	Screw
44	4343847	Screw
45	4344545	Screw
46	4343661	Clamp
48	4343749	Screw
49	4344297	Cabinet, Brace
50	4344396	Screw
51	4344289	Axle−Roller
52	4344288	Roller−Rear
53	4344292	Screw
54	4344287	Plug, Button
55	4344283	Drain Tube
58	4343777	Clamp, Tube

Following Parts Not Illustrated and Optional Parts Not Included

Part No.	DESCRIPTION
978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE

4.5 Ozs.
(R−134A)

SHELF PARTS

For Models: GB22DKXGW00, GB22DKXGN00, GB22DKXGB00
(White) (Almond) (Black)



Illus. No.	Part No.	DESCRIPTION
1	4344581	Support, Crisper RS
2	4344580	Support, Crisper LS
3	4344579	Ice Bucket
4	4344247	Shelf, Frz. Wire
5	4344237	Basket, Freezer
6	4344242	Handle, Basket
7	4344244	Track, Shelf
8	2174486	Shelf Assy, S/G
9	4344236	Meat Pan
10	4344381	Shelf, Meat Pan S/G
11	4344243	Frame Assy, S/O
12	4344380	Shelf, S/G, S/O
13	4344168	Rack, Ice Tray
14	4344171	Tray, Ice Cube
15	4344239	Spacer
16	4344238	Screw
17	4344252	Crisper Pan
18	4344255	Support, Crisper Cvr
19	4344256	Gasket
20	4344254	Cover, Pan
21	4344383	Glass, Crisper Cover
22	4344322	Ladder, Center
23	4344323	Ladder, Side
24	4344396	Screw
25	4344324	Screw
26	2192761	Trim, Meat Pan
27	2194106	Slide, Humidity Control
28	2179343	Body, Humidity Control
29	2165877	Trim, Crisper pan
30	4343675	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LITERATURE AND OPTIONAL PARTS

For Models: GB22DKXGW00, GB22DKXGN00, GB22DKXGB00
(White) (Almond) (Black)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

Customer Touch−Up Material

	*350942	Primer, White (13 Oz. Spray Can)
	*350939	Enamel, Black (13 Oz. Spray Can)
	*350930	Enamel, White (13 Oz. Spray Can)
	*350956	Enamel, Almond (13 Oz. Spray Can)
	72017	Brush Touch−Up Kit (White)
	72107	Brush Touch−Up Kit (Almond)
	72032	Brush Touch−up kit (Black)

* not to be used where the paint may make contact with the door gaskets.

Miscellaneous

	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Kit, Insulation (2 Pcs. x 3" x 24" X 48")
	876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")
	978941	Insulation, Fiberglass (63−1/2" x 35−1/2" X 2−5/8)
	876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
	505587	Sealer, Mastic (1 Qt.)
	503695	Cork, Sealer (1/4 Pound)
	511873	Touch−Up, White Porcelain (2 Oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1−1/4 Oz.)
	606755	Bag, Insulation (36−5/8" x 46")
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	833938	Kit, Terminal Connector
	4343700	Ice Container Assembly

Refinishing Material

	799340	Enamel, Black (1 Qt. Uncut)
	799344	Enamel, White (1 Qt. Uncut)
	978883	Enamel, Almond (1 Qt. Uncut)

LITERATURE PARTS

	LIT4344136	Use & Care Guide
	LIT4344141	Tech Sheet

TORX SCREW WRENCH

	1117510	Torx Key

ICE MAKER FIELD INSTALLABLE

	4344173	AMKIT97